

product	function	Lite2					Air					Air Cross				
		stabilization	record control	photo control	Focusing control	External power supply	(photo control needs the connection by shutter cable)					(photo control needs the connection by shutter cable)				
Canon	EOS-1Ds Mark III	OK	OK		OK	NA					NA					
	EOS-1D X Mark II	OK	OK		OK	NA					NA					
	EOS-1D X	OK	OK		OK	NA					NA					
	EOS-1D Mark IV	OK	OK		OK	NA					NA					
	EOS 80D	OK	OK		OK	NA	OK	OK	OK	OK	NA	OK	OK	OK	OK	
	EOS 800D	OK	OK		OK	NA	OK	OK	OK	OK	NA	OK	OK	OK	OK	
	EOS 7D Mark II	OK	OK		OK	NA	OK	OK	OK	OK	NA	OK	OK	OK	OK	
	EOS 7D	OK	OK		OK	NA	OK	OK	OK	OK	NA	OK	OK	OK	OK	
	EOS 70D	OK	OK		OK	NA	OK	OK	OK	OK	NA	OK	OK	OK	OK	
	EOS 6D Mark II	OK	OK		OK	NA	OK	OK	OK	OK	NA	OK	OK	OK	OK	
	EOS 6D	OK	OK		OK	NA	OK	OK	OK	OK	NA	OK	OK	OK	OK	
	EOS 60D	OK	OK		OK	NA	OK	OK	OK	OK	NA	OK	OK	OK	OK	
	OS 5DS / EOS 5DS	OK	OK		OK	NA	OK	OK	OK	OK	NA	OK	OK	OK	OK	
EOS 5D Mark IV	OK	OK		OK	NA	OK	OK	OK	OK	NA	OK	OK	OK	OK		
EOS 5D Mark III	OK	OK		OK	NA	OK	OK	OK	OK	NA	OK	OK	OK	OK		
EOS 5D Mark II	OK	OK		OK	NA	OK	OK	OK	OK	NA	OK	OK	OK	OK		
Sony	α9	OK	NOK		NOK	NA	OK	NOK	OK	NOK	NA	OK	NOK	OK	NOK	NOK
	α7R III	OK	NOK		NOK	NA	OK	NOK	OK	NOK	NA	OK	NOK	OK	NOK	NOK
	α7S II	OK	OK		NOK	NA	OK	OK	OK	NOK	NA	OK	OK	OK	NOK	OK
	α7R II	OK	OK		NOK	NA	OK	OK	OK	NOK	NA	OK	OK	OK	NOK	OK
	α7S	OK	OK		NOK	NA	OK	OK	OK	NOK	NA	OK	OK	OK	NOK	OK
	α7R	OK	OK		NOK	NA	OK	OK	OK	NOK	NA	OK	OK	OK	NOK	OK
	α7 II	OK	OK		NOK	NA	OK	OK	OK	NOK	NA	OK	OK	OK	NOK	OK
	α7	OK	OK		NOK	NA	OK	OK	OK	NOK	NA	OK	OK	OK	NOK	OK
	RX10 IV	OK	NOK		NOK	NA	OK	NOK	OK	NOK	NA	OK	NOK	OK	NOK	NOK
	RX100 V	OK			NOK	NA	OK	待測	待測	NOK	NA	OK	待測	待測	NOK	NOK
	RX100 IV	OK	OK		NOK	NA	OK	OK	OK	NOK	NA	OK	OK	OK	NOK	NOK
α6000	OK	OK		NOK	NA	OK	OK	OK	NOK	NA	OK	OK	OK	NOK	OK	
α6500	OK	OK		NOK	NA	OK	OK	OK	NOK	NA	OK	OK	OK	NOK	OK	
α6300	OK	OK		NOK	NA	OK	OK	OK	NOK	NA	OK	OK	OK	NOK	OK	
Panasonic	DC-GH3GK	OK	OK		NOK	NA	OK	OK	OK	NOK	NA	OK	OK	OK	NOK	OK
	DC-GH4GK	OK	OK		NOK	NA	OK	OK	OK	NOK	NA	OK	OK	OK	NOK	OK
	DC-GH5GK	OK	OK		NOK	NA	OK	OK	OK	NOK	NA	OK	OK	OK	NOK	OK
Nikon	D3400	OK	NOK		NOK	NA	OK	NOK	OK	NOK	NA	OK	NOK	OK	NOK	NOK
	D5	OK	NOK		NOK	NA	OK	NOK	OK	NOK	NA	OK	NOK	OK	NOK	NOK
	D500	OK	NOK		NOK	NA	OK	NOK	OK	NOK	NA	OK	NOK	OK	NOK	NOK
	D5300	OK	NOK		NOK	NA	OK	NOK	OK	NOK	NA	OK	NOK	OK	NOK	NOK
	D5600	OK	NOK		NOK	NA	OK	NOK	OK	NOK	NA	OK	NOK	OK	NOK	NOK
	D610	OK	NOK		NOK	NA	OK	NOK	OK	NOK	NA	OK	NOK	OK	NOK	NOK
	D7100	OK	NOK		NOK	NA	OK	NOK	OK	NOK	NA	OK	NOK	OK	NOK	NOK
	D7200	OK	NOK		NOK	NA	OK	NOK	OK	NOK	NA	OK	NOK	OK	NOK	NOK
	D750	OK	NOK		NOK	NA	OK	NOK	OK	NOK	NA	OK	NOK	OK	NOK	NOK
	D7500	OK	NOK		NOK	NA	OK	NOK	OK	NOK	NA	OK	NOK	OK	NOK	NOK
	D810	OK	NOK		NOK	NA	OK	NOK	OK	NOK	NA	OK	NOK	OK	NOK	NOK
	D810A	OK	NOK		NOK	NA	OK	NOK	OK	NOK	NA	OK	NOK	OK	NOK	NOK
	D850	OK	NOK		NOK	NA	OK	NOK	OK	NOK	NA	OK	NOK	OK	NOK	NOK
Df	OK	NOK		NOK	NA	OK	NOK	OK	NOK	NA	OK	NOK	OK	NOK	NOK	
Blackmagic Design	BMCC	OK	OK	NA	NOK	NA					NA					
	BMMCC	OK	OK	NA	NOK	NA					NA					
	BMMSC 4K	OK	OK	NA	NOK	NA					NA					
	BMPC 4K	OK	OK	NA	NOK	NA					NA					
	BMPPC	OK	OK	NA	NOK	NA	OK	OK			NA	OK	OK			
	URSA Mini 4.6K					NA					NA					
	URSA Mini 4K					NA					NA					
URSA Mini Pro					NA					NA						